



User Manual



More Languages

1

2

3

4

5



Typology and Installation Requirements



Room No. and Building No. Settings



Installation and Wiring




Configuration

1 Typology and Installation Requirements




Typology

- Maximum 16 distributors (DS-KAD7063) can be cascaded.
- The name tag and call button are replaceable, you can replace them according to actual need. Here takes door station with 4 call buttons as an example.




Star Connection



Daisy Chain Connection

Installation Requirements

Unit: m [feet]



Cable Type	DS-KAD7063EY to Door Station	DS-KAD7063EY to Indoor Station	Indoor Station to Indoor Station	Indoor Station to Door Station
UTP 5 0.2 mm ² (Cat.5) AWG24	60 m	60 m	100 m	140 m
0.28 mm ² (TP) AWG23	60 m	40 m	80 m	160 m
0.5 mm ² (parallel) AWG20	60 m	60 m	100 m	180 m
1 mm ² (parallel) AWG17	60 m	60 m	100 m	260 m
1 mm ² (TP) AWG17	60 m	40 m	80 m	260 m
1.5 mm ² (parallel) AWG15	60 m	60 m	100 m	260 m

2 Room No. and Building No. Settings



i

- Press and hold the first button / call button for more than 5 s until the voice prompt "beep" is heard. Release to trigger AP activation or renewal.
- By default, the AP mode would automatically closed after 30 min.

i

- By default, DIP1/2 are set for door station with 1 call button.
- For door station with 2 call buttons, set DIP 1 as 1.
- For door station with 4 call buttons, set DIP 2 as 1.

Door Station

For example:



Building No. (01 to 99): 01



Door Station Type: 00

i


Door Station Types:
Main Door Station: 00
Sub Door Station: 01 to 16



Door Open Duration


Rotary Switch	Door Open Duration (s)
0	2
1	1
2	3
3	4
4	5
5	8
6	10
7/8/9	Reserved

Reserved



Rotary Switch

For example:



Indoor Station

i

- It is recommended to remark the indoor station No. on the back of the device sticker to indicate the Indoor Station No.

i

Indoor Station Type: 0
Indoor Station Types:
Main Indoor Station: 0
Indoor Extension: 1 to 3

i

Make sure the indoor station's building No. is the same as the door station in this building's, or the door station cannot call the indoor station in the same building.

Room No. (1 to 400): 323

i

- DIP 1 and DIP 2 are for mode settings, and DIP 3 and DIP 4 are reserved.
- The device is on debugging mode when the extension No. is 9.

About this Document

- This Document includes instructions for using and managing the Product. Pictures, charts, images and all other information hereinafter are for description and explanation only.
- The information contained in the Document is subject to change, without notice, due to firmware updates or other reasons. Please find the latest version of the Document at the Hikvision website (<https://www.hikvision.com>). Unless otherwise agreed, Hangzhou Hikvision Digital Technology Co., Ltd. or its affiliates (hereinafter referred to as "Hikvision") makes no warranties, express or implied.
- Please use the Document with the guidance and assistance of professionals trained in supporting the Product.

About this Product

This product can only enjoy the after-sales service support in the country or region where the purchase is made.

Acknowledgment of Intellectual Property Rights





- Hikvision owns the copyrights and/or patents related to the technology embodied in the Products described in this Document, which may include licenses obtained from third parties.
- Any part of the Document, including text, pictures, graphics, etc., belongs to Hikvision. No part of this Document may be excerpted, copied, translated, or modified in whole or in part by any means without written permission.
- **HIKVISION** and other Hikvision's trademarks and logos are the properties of Hikvision in various jurisdictions.
- Other trademarks and logos mentioned are the properties of their respective owners.

LEGAL DISCLAIMER

- TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, THIS DOCUMENT AND THE PRODUCT DESCRIBED, WITH ITS HARDWARE, SOFTWARE AND FIRMWARE, ARE PROVIDED "AS IS" AND "WITH ALL FAULTS AND ERRORS". HIKVISION MAKES NO WARRANTIES, EXPRESS OR IMPLIED, INCLUDING WITHOUT LIMITATION, MERCHANTABILITY, SATISFACTORY QUALITY, OR FITNESS FOR A PARTICULAR PURPOSE. THE USE OF THE PRODUCT BY YOU IS AT YOUR OWN RISK. IN NO EVENT WILL HIKVISION BE LIABLE TO YOU FOR ANY SPECIAL, CONSEQUENTIAL, INCIDENTAL, OR INDIRECT DAMAGES, INCLUDING, AMONG OTHERS, DAMAGES FOR LOSS OF BUSINESS PROFITS, BUSINESS INTERRUPTION, OR LOSS OF DATA, CORRUPTION OF SYSTEMS, OR LOSS OF DOCUMENTATION, WHETHER BASED ON BREACH OF CONTRACT, TORT (INCLUDING NEGLIGENCE), PRODUCT LIABILITY, OR OTHERWISE, IN CONNECTION WITH THE USE OF THE PRODUCT, EVEN IF HIKVISION HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES OR LOSS.
- YOU ACKNOWLEDGE THAT THE NATURE OF THE INTERNET PROVIDES FOR INHERENT SECURITY RISKS, AND HIKVISION SHALL NOT TAKE ANY RESPONSIBILITIES FOR ABNORMAL OPERATION, PRIVACY LEAKAGE OR OTHER DAMAGES RESULTING FROM CYBER-ATTACK, HACKER ATTACK, VIRUS INFECTION, OR OTHER INTERNET SECURITY RISKS; HOWEVER, HIKVISION WILL PROVIDE TIMELY TECHNICAL SUPPORT IF REQUIRED.
- YOU AGREE TO USE THIS PRODUCT IN COMPLIANCE WITH ALL APPLICABLE LAWS, AND YOU ARE SOLELY RESPONSIBLE FOR ENSURING THAT YOUR USE CONFORMS TO THE APPLICABLE LAW. ESPECIALLY, YOU ARE RESPONSIBLE, FOR USING THIS PRODUCT IN A MANNER THAT DOES NOT INFRINGE ON THE RIGHTS OF THIRD PARTIES, INCLUDING WITHOUT LIMITATION, RIGHTS OF PUBLICITY, INTELLECTUAL PROPERTY RIGHTS, OR DATA PROTECTION AND OTHER PRIVACY RIGHTS. YOU SHALL NOT USE THIS PRODUCT FOR ANY PROHIBITED END-USES, INCLUDING THE DEVELOPMENT OR PRODUCTION OF WEAPONS OF MASS DESTRUCTION, THE DEVELOPMENT OR PRODUCTION OF CHEMICAL OR BIOLOGICAL WEAPONS, ANY ACTIVITIES IN THE CONTEXT RELATED TO ANY NUCLEAR EXPLOSIVE OR UNSAFE NUCLEAR FUEL-CYCLE, OR IN SUPPORT OF HUMAN RIGHTS ABUSES.
- IN THE EVENT OF ANY CONFLICTS BETWEEN THIS DOCUMENT AND THE APPLICABLE LAW, THE LATTER PREVAILS.

© Hangzhou Hikvision Digital Technology Co., Ltd. All rights reserved.


3 Installation




Door Station Installation

i The name tag and call button are replaceable, you can replace them according to actual need. Here takes door station with one call button as an example.


Surface Mounting with Rain Shield




Surface Mounting without Rain Shield




Indoor Station Installation



Distributor Installation




4 Wiring




! Make sure no wires are bare when connecting.

i The 2-wire cable between 2 devices should be undivided. Using discontinuous cables for connecting will cause impact on the power supply and communication.




i CH1/CH2 can connect to the door station.
• CH3 to CH6 interfaces can connect to indoor station.

i *The Exit Button 1 is for unlocking door 1.
**The Exit Button 2 is for unlocking door 2 (Disabled by default).
***LOCK 1 is a 20 V/4 A impulse output with 300 mA holding current.



! Make sure no wires are bare when connecting.

i The 2-wire cable between 2 devices should be undivided. Using discontinuous cables for connecting will cause impact on the power supply and communication.




i CH1/CH2 can connect to the door station.
• CH3 to CH6 interfaces can connect to indoor station.


i *The Exit Button 1 is for unlocking door 1.
**The Exit Button 2 is for unlocking door 2 (Disabled by default).
***LOCK 1 is a 20 V/4 A impulse output with 300 mA holding current.

5 Configuration

5.1 Configuration Power On




5.2 Configuration Connection Test




5.3 Configuration Door Station Additional Configuration

Adjust Loudspeaker/Mic Volume



Reset Factory Settings



Reset AP Mode Password

