




Quick Installation Guide

Cloud L2+ Managed PoE Switch




WI-PCMS310GF(V2) | WI-PCMS328GF(V2)

www.wireless-tek.com


1. Packing Content




Switch x 1



Quick Installation Guide x 1



Serial Line x 1



Power Cord x 1




Mounting Accessories
(hook x 2, mats x 4, screw x 8)


2. Appearance Overview

WI-PCMS310GF

• Front panel



• Back panel




• LED indicator and button


LED indicators & button	Description
SYS	Blinking: The Device system is operating normally Off: Device system or power connection abnormality
PWR	On: The device power on is normal Off: The device is power off or failed
PoE	On: Equipment connected, normal power supply Off: Port not for terminal equipment power supply
Link	On: Port connected Blinking: Data transmission Off: Port disconnected
Reset	Hold for >5 sec. to restore factory default

WI-PCMS328GF

• Front panel



• Back panel




• LED indicator and button

LED indicators & button	Description
SYS	Blinking: The Device system is operating normally Off: Device system or power connection abnormality
PWR	On: The device power on is normal Off: The device is power off or failed
PoE	On: Equipment connected, normal power supply Off: Port not for terminal equipment power supply
Link	On: Port connected Blinking: Data transmission Off: Port disconnected
Reset	Hold for >5 sec. to restore factory default


3. Installation

• Desktop Installation



Step1: Attach the mats to the bottom four corners of the switch.



Step2: Place the switch horizontally on the desktop.



• Rack-mount Installation



4. Configuration

• Desktop Installation

Step1: Attach the mats to the bottom four corners of the switch.



Step2: Place the switch horizontally on the desktop.



• Rack-mount Installation



5. Management

• Log in to the switch locally

Let the Switch obtain an IP address and then check the DHCP server to see which IP address was assigned.

The Switch is set to DHCP by default, so it will try to obtain an IP address automatically.

If that fails, then it will use the default fallback IP address, 192.168.0.1

Notice:


Step 2 is your computer recognizes the COM number of the Console line

Step 3 is the baud rate of the switch (the baud rate of the switch is 9600)



• Use the console cable to access the switch

Connection Diagram:



5. Management

• Log in to the switch locally

Let the Switch obtain an IP address and then check the DHCP server to see which IP address was assigned.


The Switch is set to DHCP by default, so it will try to obtain an IP address automatically.

If that fails, then it will use the default fallback IP address, 192.168.0.1

Notice:


Step 2 is your computer recognizes the COM number of the Console line

Step 3 is the baud rate of the switch (the baud rate of the switch is 9600)



• Use the console cable to access the switch


Connection Diagram:




3. Installation

• Desktop Installation


Step1: Attach the mats to the bottom four corners of the switch.



Step2: Place the switch horizontally on the desktop.




• Rack-mount Installation




4. Configuration

• Desktop Installation



Step1: Attach the mats to the bottom four corners of the switch.



Step2: Place the switch horizontally on the desktop.




• Rack-mount Installation



4. Configuration

• Desktop Installation


Step1: Attach the mats to the bottom four corners of the switch.



Step2: Place the switch horizontally on the desktop.



• Rack-mount Installation



5. Management

• Log in to the switch locally

Let the Switch obtain an IP address and then check the DHCP server to see which IP address was assigned.


The Switch is set to DHCP by default, so it will try to obtain an IP address automatically.

If that fails, then it will use the default fallback IP address, 192.168.0.1

Notice:


Step 2 is your computer recognizes the COM number of the Console line

Step 3 is the baud rate of the switch (the baud rate of the switch is 9600)



• Use the console cable to access the switch

Connection Diagram:



5. Management

• Log in to the switch locally

Let the Switch obtain an IP address and then check the DHCP server to see which IP address was assigned.

The Switch is set to DHCP by default, so it will try to obtain an IP address automatically.

If that fails, then it will use the default fallback IP address, 192.168.0.1

Notice:


Step 2 is your computer recognizes the COM number of the Console line

Step 3 is the baud rate of the switch (the baud rate of the switch is 9600)




• Use the console cable to access the switch

Connection Diagram:



2. Enter the cloud binding switch

(Explain: The switch must be connected to the internet to bind successfully)



• Cloud login switch configuration


1. Log in to the cloud management page

(No account, you need to register an account to log in, The URL is http://cloud2.wireless-tek.com)




• Use the console cable to access the switch

Connection Diagram:



3. After binding, you can use the Switch in the Tunnel option in the cloud management, and then use EWEB to enter the switch.


(After entering the switch, you can configure it based on your own needs)



• Cloud login switch configuration


1. Log in to the cloud management page

(No account, you need to register an account to log in, The URL is http://cloud2.wireless-tek.com)



• Use the console cable to access the switch

Connection Diagram:



Warranty Card

Username	
Address	
Telephone No.	
Purchase Shop	
Purchase Address	
Product Model No.	
Purchase Time	
Serial No.	
Dealer Signature	

- If the product defects within the warranty period, we will provide professional maintenance service.
- Proof of purchase and a complete product serial number are required to receive any services guaranteed as part of the limited warranty.
- Any other defects that are not caused by workmanship or product quality, such as natural disasters, water damage, extreme thermal or environmental conditions, sticker damaged, warranty card loss will disqualify the product from limited warranty.



Technical Support Company Website Cloud Management

Wireless-Tek Technology Limited
Address: Building 3, Units 1801-1807, 1812, Huangliang Era Plaza, Tangwei Community, Fuhai Street, Bao'an District, Shenzhen City, Guangdong Province, China.
Website: www.wireless-tek.com
Tel: 86-0755-32811290
Email: sales@wireless-tek.com
Technical Support: tech@wireless-tek.com

