















Network Speed Dome

Quick Start Guide


Symbols and Marks



	Notice		i. Not necessarily included accessory. ii. Variable accessory amount. iii. Skip this step if not required.
	Warning	microSD 	MicroSD card
	Forbidden		Purchase separately
	Correct		Disposal
	Incorrect		Functional grounding
	Turn to page A and continue.		Grounding
	Other situations		Skip this step if not necessary
	Waterproof		Other situations omitted


1.



2.







1x



1x



1x



HSFM6×12

1x



3x



1x







2x*







2x












1.1




1.2




1.3




1.4




1.5



1.6



1.7






Product appearance is for reference only and may differ from the actual product.

Interface (Page 5)

- ① Memory card slot
- ② Reset
- ③ SIM card slot
- ④ Network interface
- ⑤ Alarm & Audio interface
- ⑥ RS-485 & Power input
- ⑦ Grounding

Alarm Output



- ① Relay output
- ② DC load
- ③ Power supply
- ④ JQC-3FG Relay



Protective Measures for Outdoor Installation



Activate and Access Network Camera

