










Network Speed Dome


Quick Start Guide








1x



1x



2x*



1x



3x



M8×105

1x



1x




HSCSM4×14

1x



1x



1x



1x



M8×105

1x




3x



3x



1x



14mm

28mm

32mm





5.0




2.0

Ø12.5mm






1x



1x



2x*



1x



3x



M6×70

1x



1x




HSCSM4×14

1x



1x



1x



1x



M8×105

1x




3x



3x



1x



10mm

14mm


28mm


32mm




Ø10.5mm


Ø12.5mm









1.1




1.2




1.3




1.4




1.5




1.6




1.7




2.1




2.2




2.3




3.1




3.2




3.3






3.4




3.5







Alarm Output



- ① Relay output
- ② DC load
- ③ Power supply
- ④ JQC-3FG relay



Activate and Access Network Camera



Product appearance is for reference only and may differ from the actual product.

Interface (Page 5 to 6)

- ① Network interface
- ② RS-485 interface
- ③ Power input interface
- ④ Audio interface
- ⑤ Alarm interface
- ⑥ Reset button
- ⑦ MicroSD card
- ⑧ SoC
- ⑨ SIM card slot

Note: The interface varies with the models. Please refer to the product datasheet for details.



See Far, Go Further