



Hikvision Card Reader DIP Switch Settings




Address 1 - Door 1 Entrance Card Reader




Address 5 - Door 3 Entrance Card Reader




Address 2 - Door 1 Exit Card Reader




Address 6 - Door 3 Exit Card Reader




Address 3 - Door 2 Entrance Card Reader



Address 7 - Door 4 Entrance Card Reader



Address 4 - Door 2 Exit Card Reader



Address - Door 4 Exit Card Reader