





Quick Installation Guide

PoE Injector




WI-POE31-48V | WI-POE51-48V (V2)

1. Packing Content



1 x Injector



1 x AC Power Cord




1 x Installation Guide

2. Appearance Overview


WI-POE31-48V

- Front panel



AC IN 100-240V

- Back panel




1*10/100Mbps Ethernet Data Input
1*10/100Mbps 48V PoE Output

- LED indicator

LED Indicators	Description
Power	On: The device power on is normal Off: The device is power off or failed


WI-POE51-48V (V2)

- Front panel



AC IN 100-240V

- Back panel




1*10/100/1000Mbps 802.3af/at PoE+ Output
1*10/100/1000Mbps Ethernet Data Input

- LED indicator

LED Indicators	Description
Power	On: The device power on is normal Off: The device is power off or failed

3.Installation

- Desktop Installation



Warranty Card

Username	
Address	
Telephone No.	
Purchase Shop	
Purchase Address	
Product Model No.	
Purchase Time	
Serial No.	
Dealer Signature	

- If the product defects within the warranty period, we will provide professional maintenance service.
- Proof of purchase and a complete product serial number are required to receive any services guaranteed as part of the limited warranty.
- Any other defects that are not caused by workmanship or product quality, such as natural disasters, water damage, extreme thermal or environmental conditions, sticker damaged, warranty card loss will disqualify the product from limited warranty.



Technical Support



Company Website



Cloud Management

Wireless-Tek Technology Limited
Address: Building 3, Units 1801-1807, 1812,
Huaqiang Era Plaza, Tangwei Community,
Fuhai Street, Bao'an District, Shenzhen City,
Guangdong Province, China.
Website: www.wireless-tek.com
Tel: 86-0755-32811290
Email: sales@wireless-tek.com
Technical Support: tech@wireless-tek.com

