


Quick Installation Guide


250m CCTV PoE Switch




WI-PS206S(V2) | WI-PS210S(V2) | WI-PS210GS(V2)

www.wireless-tek.com

1. Package Contents



Switch x 1



1 x Power Cord




1 x Installation Guide

2. Appearance Overview

For WI-PS206S

• Front panel



LED Indicator

DIP Switch

1 * 10/100Mbps Hi-PoE 60W Port

3 * 10/100Mbps 802.3af/at PoE+ Ports

2 * 10/100Mbps Uplink Ports

• Back panel



Grounding


AC 100~240V Input Power Port

• DIP Switch Description and LED Indicator

WI-PS206S DIP Switch Description	
VLAN	All downlink ports are isolated from each other, but can communicate with uplink ports.
PD Alive	All PoE ports enable PoE watchdog function, which can detect and reboot the offline compliant PoE powered devices.
Extend	The transmission distance of port can be up to 250m, but the rate is limited to 10Mbps.
LED Indicators	
PWR	Solid on: The system power supply is normal. Off: The system power supply is abnormal.
Link(Port 1-6)	Solid on: A link has been established on the interface. Blinking: Data is being transmitted or received on the interface. Off: No link is established on the interface.

For WI-PS210S

• Front panel



LED Indicator

DIP Switch

1 * 10/100Mbps Hi-PoE 60W Port

7 * 10/100Mbps 802.3af/at PoE+ Ports

2 * 10/100Mbps Uplink Ports

• Back panel



Grounding


AC 100~240V Input Power Port

• DIP Switch Description and LED Indicator

WI-PS210S DIP Switch Description	
VLAN	All downlink ports are isolated from each other, but can communicate with uplink ports.
PD Alive	All PoE ports enable PoE watchdog function, which can detect and reboot the offline compliant PoE powered devices.
Extend	The transmission distance of port can be up to 250m, but the rate is limited to 10Mbps.
LED Indicators	
PWR	Solid on: The system power supply is normal. Off: The system power supply is abnormal.
Link(Port 1-10)	Solid on: A link has been established on the interface. Blinking: Data is being transmitted or received on the interface. Off: No link is established on the interface.

For WI-PS210GS

• Front panel



LED Indicator

DIP Switch

1 * 10/100Mbps Hi-PoE 60W Port

7 * 10/100Mbps 802.3af/at PoE+ Ports

2 * 10/100Mbps Uplink Ports

• Back panel



Grounding

AC 100~240V Input Power Port

• DIP Switch Description and LED Indicator


WI-PS210GS DIP Switch Description	
VLAN	All downlink ports are isolated from each other, but can communicate with uplink ports.
PD Alive	All PoE ports enable PoE watchdog function, which can detect and reboot the offline compliant PoE powered devices.
Extend	The transmission distance of port can be up to 250m, but the rate is limited to 10Mbps.
LED Indicators	
PWR	Solid on: The system power supply is normal. Off: The system power supply is abnormal.
Link(Port 1-10)	Solid on: A link has been established on the interface. Blinking: Data is being transmitted or received on the interface. Off: No link is established on the interface.

DIP Switch Function Option

DIP Switch 1,2,3: Function Option				
VLAN	PD Alive	Extend	SW Indicator Status	Description
Down	Down	Down	Off	No function select.
Down	Up	Down	Off	PD Alive mode enabled.
Down	Down	Up	1/2s Blinking	Extend mode enabled.
Down	Up	Up	1/2s Blinking	Extend mode and PD Alive mode enabled.
Up	Down	Down	Solid on	VLAN mode enabled.
Up	Up	Down	Solid on	VLAN mode and PD Alive mode enabled.
Up	Down	Up	1/4s Blinking	VLAN mode and Extend mode enabled.
Up	Up	Up	1/4s Blinking	VLAN mode, Extend mode and PD Alive mode enabled.


3. Installation

• 3.1 Desktop Installation



• 3.2 Wall-mount Installation

Install the Switch by following the steps: Fix 2 screws on the wall to align the 2 fixing holes on the Switch, as shown in the figure below, and hang the Switch smoothly on the screws.



Warranty Card

Username	
Address	
Telephone No.	
Purchase Shop	
Purchase Address	
Product Model No.	
Purchase Time	
Serial No.	
Dealer Signature	

- If the product defects within the warranty period, we will provide professional maintenance service.
- Proof of purchase and a complete product serial number are required to receive any services guaranteed as part of the limited warranty.
- Any other defects that are not caused by workmanship or product quality, such as natural disasters, water damage, extreme thermal or environmental conditions, sticker damaged, warranty card loss will disqualify the product from limited warranty.



Wireless-Tek Technology Limited
Address: Building 3, Units 1801-1807, 1812,
Huaqiang Era Plaza, Tangwei Community,
Fuhai Street, Bao'an District, Shenzhen City,
Guangdong Province, China.
Website: www.wireless-tek.com
Tel: 86-0755-32811290
Email: sales@wireless-tek.com
Technical Support: tech@wireless-tek.com

